

ANALYZED BY:

Anresco Laboratories
1375 Van Dyke Avenue,
San Francisco, CA 94124

CUSTOMER:

Surly Brewing Company
4811 Dusharme Dr
Brooklyn Center, MN 55429





SAMPLE INFORMATION

Sample No.: 1330012
Product Name: Find Wunder: Higher Vibes Blood Orange Bitters
Matrix: Edible (Carbonated Beverage)
Lot #: WSTBB107

Date Collected: 08/13/2025
Date Received: 08/13/2025
Date Reported: 08/15/2025

TEST SUMMARY

Cannabinoid Profile: ✔ Pass
Residual Solvent Screen: ✔ Pass
Foreign Material: ✔ Pass

Pesticide Residue Screen: Pass
Heavy Metal Screen:  Pass
Mycotoxin Screen:  Pass

Cannabinoid Profile **Pass**

08/15/2025

Method:	MF-CHEM-15
Instrument:	Liquid Chromatography Diode Array Detector (LC-DAD)
Limit of Detection	0.0008 mg/g
Limit of Quantitation	0.0025 mg/g

Cannabinoid	mg/g	%	mg/ml	mg/serving	mg/package	Labeled mg/serving	% Difference	Status
Δ8-THC	ND	ND	ND	ND	ND	-	-	-
Δ9-THC	0.0289	0.00289	0.0296	5.24	10.47	5	4.73	Pass
Δ9-THCA	ND	ND	ND	ND	ND	-	-	-
THCV	ND	ND	ND	ND	ND	-	-	-
THCVA	ND	ND	ND	ND	ND	-	-	-
CBD	ND	ND	ND	ND	ND	-	-	-
CBDA	ND	ND	ND	ND	ND	-	-	-
CBC	ND	ND	ND	ND	ND	-	-	-
CBCA	ND	ND	ND	ND	ND	-	-	-
CBDV	ND	ND	ND	ND	ND	-	-	-
CBG	0.0270	0.0027	0.0276	4.89	9.78	5	2.15	-
CBGA	ND	ND	ND	ND	ND	-	-	-
CBN	ND	ND	ND	ND	ND	-	-	-
Total THC	0.0289	0.00289	0.0296	5.24	10.47	-	-	-
Total CBD	ND	ND	ND	ND	ND	-	-	-
Total Cannabinoids	0.0559	0.00559	0.0572	10.13	20.26	-	-	-
Sum of Cannabinoids	0.0559	0.00559	0.0572	10.13	20.26	-	-	-
Serving Weight (g)	181.1949							
Package Weight (g)	362.3898							
g/ml Conversion Factor	1.0237							

$$\begin{aligned}\text{Total THC} &= \Delta 8\text{-THC} + \Delta 9\text{-THC} + (0.877 * \text{THCA}) \\ \text{Total CBD} &= \text{CBD} + (0.877 * \text{CBDA}) \\ \text{Total Cannabinoids} &= \Sigma (\text{neutral cannabinoids}) + [0.877 * \Sigma (\text{acidic cannabinoids})]\end{aligned}$$
Pesticide Residue Screen Pass

08/15/2025

Method: MF-CHEM-13

Instrument: Liquid Chromatography Tandem Mass Spectrometry (LC-MS/MS) & Gas Chromatography Tandem Mass Spectrometry (GC-MS/MS)

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Abamectin	0.04/0.10	ND	0.3	Pass
Acephate	0.02/0.06	ND	5.0	Pass
Acequinocyl	0.04/0.10	ND	4.0	Pass
Acetamiprid	0.017/0.05	ND	5.0	Pass

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Aldicarb	0.02/0.06	ND	0.02	Pass
Azoxystrobin	0.02/0.06	ND	40.0	Pass
Bifenazate	0.02/0.06	ND	5.0	Pass
Bifenthrin	0.04/0.10	ND	0.5	Pass
Boscalid	0.02/0.06	ND	10.0	Pass
Captan	0.2/0.6	ND	5.0	Pass
Carbaryl	0.02/0.06	ND	0.5	Pass
Carbofuran	0.017/0.05	ND	0.017	Pass
Chlorantraniliprole	0.02/0.06	ND	40.0	Pass
Chlordane	0.02/0.06	ND	0.02	Pass
Chlorfenapyr	0.02/0.06	ND	0.02	Pass
Chlorpyrifos	0.02/0.06	ND	0.02	Pass
Clofentezine	0.02/0.06	ND	0.5	Pass
Coumaphos	0.02/0.06	ND	0.02	Pass
Cyfluthrin	0.10/0.30	ND	1.0	Pass
Cypermethrin	0.10/0.30	ND	1.0	Pass
Daminozide	0.017/0.05	ND	0.017	Pass
DDVP (Dichlorvos)	0.013/0.04	ND	0.013	Pass
Diazinon	0.017/0.05	ND	0.2	Pass
Dimethoate	0.017/0.05	ND	0.017	Pass
Dimethomorph	0.017/0.05	ND	20.0	Pass
Ethoprop(hos)	0.02/0.06	ND	0.02	Pass
Etofenprox	0.02/0.06	ND	0.02	Pass
Etoxazole	0.02/0.06	ND	1.5	Pass
Fenhexamid	0.017/0.05	ND	10.0	Pass
Fenoxycarb	0.02/0.06	ND	0.02	Pass
Fenpyroximate	0.02/0.06	ND	2.0	Pass
Fipronil	0.02/0.06	ND	0.02	Pass
Flonicamid	0.02/0.06	ND	2.0	Pass
Fludioxonil	0.02/0.06	ND	30.0	Pass
Hexythiazox	0.02/0.06	ND	2.0	Pass
Imazalil	0.02/0.06	ND	0.02	Pass
Imidacloprid	0.02/0.06	ND	3.0	Pass
Kresoxim Methyl	0.02/0.06	ND	1.0	Pass
Malathion	0.017/0.05	ND	5.0	Pass
Metalaxyl	0.017/0.05	ND	15.0	Pass
Methiocarb	0.02/0.06	ND	0.02	Pass
Methomyl	0.013/0.04	ND	0.1	Pass
Methyl parathion	0.02/0.06	ND	0.02	Pass
Mevinphos	0.02/0.06	ND	0.02	Pass
Myclobutanil	0.02/0.06	ND	9.0	Pass
Naled	0.017/0.05	ND	0.5	Pass
Oxamyl	0.013/0.04	ND	0.2	Pass
Paclobutrazol	0.02/0.06	ND	0.02	Pass
Pentachloronitrobenzene	0.017/0.05	ND	0.2	Pass
Permethrins	0.10/0.30	ND	20.0	Pass
Phosmet	0.02/0.06	ND	0.2	Pass
Piperonyl Butoxide	0.02/0.06	ND	8.0	Pass
Prallethrin	0.04/0.10	ND	0.4	Pass
Propiconazole	0.02/0.06	ND	20.0	Pass
Propoxur	0.013/0.04	ND	0.013	Pass
Pyrethrins	0.15/0.50	ND	1.0	Pass
Pyridaben	0.017/0.05	ND	3.0	Pass
Spinetoram	0.02/0.06	ND	3.0	Pass
Spinosad	0.02/0.06	ND	3.0	Pass
Spiromesifen	0.04/0.10	ND	12.0	Pass
Spirotetramat	0.02/0.06	ND	13.0	Pass
Spiroxamine	0.017/0.05	ND	0.017	Pass
Tebuconazole	0.02/0.06	ND	2.0	Pass
Thiacloprid	0.013/0.04	ND	0.013	Pass
Thiamethoxam	0.02/0.06	ND	4.5	Pass
Trifloxystrobin	0.02/0.06	ND	30.0	Pass

Residual Solvent Screen ✔ Pass

08/15/2025

Method: MF-CHEM-32

Instrument: Gas Chromatography Mass Spectrometry (GC/MS)

Analyte	LOD/LOQ (ppm)	Findings (ppm)	Limit (ppm)	Status
1,2-Dichloroethane	0.5/0.5	ND	1	Pass
Acetone	57/200	ND	5000	Pass
Acetonitrile	56/200	ND	410	Pass
Benzene	0.5/0.5	ND	1	Pass
n-Butane	45/200	ND	5000	Pass
Chloroform	0.5/0.5	ND	1	Pass
Ethanol	37/200	ND	5000	Pass
Ethyl acetate	38/200	ND	5000	Pass
Ethyl ether	37/200	ND	5000	Pass
Ethylene oxide	0.1/0.5	ND	1	Pass
n-Heptane	135/200	ND	5000	Pass
n-Hexane	49/200	ND	290	Pass
Isopropyl alcohol	57/200	ND	5000	Pass
Methanol	37/200	ND	3000	Pass
Methylene chloride	0.1/0.5	ND	1	Pass
n-Pentane	37/200	ND	5000	Pass
Propane	72/200	ND	5000	Pass
Toluene	49/200	ND	890	Pass
Total xylenes (ortho-, meta-, para-)	58/200	ND	2170	Pass
Trichloroethylene	0.5/0.5	ND	1	Pass

Heavy Metal Screen ✔ Pass

08/15/2025

Method: MF-CHEM-16

Instrument: Inductively Coupled Plasma Mass Spectrometry (ICP-MS)

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Arsenic	0.003/0.05	ND	1.5	Pass
Cadmium	0.008/0.05	ND	0.5	Pass
Mercury	0.002/0.05	ND	3	Pass
Lead	0.01/0.125	ND	0.5	Pass

Foreign Material ✔ Pass

08/15/2025

Method: MF-CHEM-7

Analyte	Findings	Limit	Status
Sand, Soils, Cinders, and Dirt	ND	25%	Pass
Mold	ND	25%	Pass
Imbedded Foreign Material	ND	25%	Pass
Insect Fragment	ND	1 per 3g	Pass
Hair	ND	1 per 3g	Pass
Mammalian Excreta	ND	1 per 3g	Pass

Mycotoxin Screen ✔ Pass

08/15/2025

Method: MF-CHEM-13

Instrument: Liquid Chromatography Tandem Mass Spectrometry (LC-MS/MS) & Gas Chromatography Tandem Mass Spectrometry (GC-MS/MS)

Analyte	LOD/LOQ (µg/kg)	Findings (µg/kg)	Limit (µg/kg)	Status
Aflatoxin B1	2/5	ND	-	-
Aflatoxin B2	2/5	ND	-	-
Aflatoxin G1	2/5	ND	-	-
Aflatoxin G2	2/5	ND	-	-
Total Aflatoxins	8/20	ND	20	Pass
Ochratoxin A	6/18	ND	20	Pass

ND = None Detected
LOD = Limit of Detection
LOQ = Limit of Quantitation

Reported by



Vu Lam
Lab Co Director



Scan to verify

ANALYZED BY:

Anresco Laboratories
1375 Van Dyke Avenue,
San Francisco, CA 94124

CUSTOMER:

Surly Brewing Company
4811 Dusharme Dr
Brooklyn Center, MN 55429



SAMPLE INFORMATION

Sample No.: 1330800
Product Name: Find Wunder: Higher Vibes Blackberry Lemon
Matrix: Edible (Carbonated Beverage)
Lot #: WSTBL-122

Date Collected: 08/15/2025
Date Received: 08/15/2025
Date Reported: 08/20/2025

TEST SUMMARY

Cannabinoid Profile: ✔ Pass
Pesticide Residue Screen: ✔ Pass
Heavy Metal Screen: ✔ Pass
Mycotoxin Screen: ✔ Pass

Microbiological Screen: ✔ Pass
Residual Solvent Screen: ✔ Pass
Foreign Material: ✔ Pass

Cannabinoid Profile ✔ Pass

08/19/2025

Method: MF-CHEM-15
Instrument: Liquid Chromatography Diode Array Detector (LC-DAD)
Limit of Detection 0.0008 mg/g
Limit of Quantitation 0.0025 mg/g

Cannabinoid	mg/g	%	mg/ml	mg/serving	mg/package	Labeled mg/serving	% Difference	Status
Δ8-THC	ND	ND	ND	ND	ND	-	-	-
Δ9-THC	0.0281	0.00281	0.0287	5.08	10.16	5	1.63	Pass
Δ9-THCA	ND	ND	ND	ND	ND	-	-	-
THCV	ND	ND	ND	ND	ND	-	-	-
THCVA	ND	ND	ND	ND	ND	-	-	-
CBD	ND	ND	ND	ND	ND	-	-	-
CBDA	ND	ND	ND	ND	ND	-	-	-
CBC	ND	ND	ND	ND	ND	-	-	-
CBCA	ND	ND	ND	ND	ND	-	-	-
CBDV	ND	ND	ND	ND	ND	-	-	-
CBG	0.0263	0.00263	0.0269	4.76	9.51	5	4.88	-
CBGA	ND	ND	ND	ND	ND	-	-	-
CBN	ND	ND	ND	ND	ND	-	-	-
Total THC	0.0281	0.00281	0.0287	5.08	10.16	-	-	-
Total CBD	ND	ND	ND	ND	ND	-	-	-
Total Cannabinoids	0.0544	0.00544	0.0556	9.84	19.68	-	-	-
Sum of Cannabinoids	0.0544	0.00544	0.0556	9.84	19.68	-	-	-
Serving Weight (g)	180.8409							
Package Weight (g)	361.6818							
g/ml Conversion Factor	1.0217							

Total THC = Δ8-THC + Δ9-THC + (0.877 * THCA)
Total CBD = CBD + (0.877 * CBDA)
Total Cannabinoids = Σ (neutral cannabinoids) + [0.877 * Σ (acidic cannabinoids)]

Microbiological Screen ✔ Pass

08/19/2025

Analyte	Method	Findings	Units	Status
Salmonella	MF-MICRO-11	Not Detected/25g	/1g	Pass
STEC	MF-MICRO-18	Not Detected/25g	/1g	Pass

Pesticide Residue Screen ✔ Pass

08/20/2025

Method: MF-CHEM-13

Instrument: Liquid Chromatography Tandem Mass Spectrometry (LC-MS/MS) & Gas Chromatography Tandem Mass Spectrometry (GC-MS/MS)

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Abamectin	0.04/0.10	ND	0.3	Pass
Acephate	0.02/0.06	ND	5.0	Pass
Acequinocyl	0.04/0.10	ND	4.0	Pass
Acetamiprid	0.017/0.05	ND	5.0	Pass
Aldicarb	0.02/0.06	ND	0.02	Pass
Azoxystrobin	0.02/0.06	ND	40.0	Pass
Bifenazate	0.02/0.06	ND	5.0	Pass
Bifenthrin	0.04/0.10	ND	0.5	Pass
Boscalid	0.02/0.06	ND	10.0	Pass
Captan	0.2/0.6	ND	5.0	Pass
Carbaryl	0.02/0.06	ND	0.5	Pass
Carbofuran	0.017/0.05	ND	0.017	Pass
Chlorantraniliprole	0.02/0.06	ND	40.0	Pass
Chlordane	0.02/0.06	ND	0.02	Pass
Chlorfenapyr	0.02/0.06	ND	0.02	Pass
Chlorpyrifos	0.02/0.06	ND	0.02	Pass
Clofentezine	0.02/0.06	ND	0.5	Pass
Coumaphos	0.02/0.06	ND	0.02	Pass
Cyfluthrin	0.10/0.30	ND	1.0	Pass
Cypermethrin	0.10/0.30	ND	1.0	Pass
Daminozide	0.017/0.05	ND	0.017	Pass
DDVP (Dichlorvos)	0.013/0.04	ND	0.013	Pass
Diazinon	0.017/0.05	ND	0.2	Pass
Dimethoate	0.017/0.05	ND	0.017	Pass
Dimethomorph	0.017/0.05	ND	20.0	Pass
Ethoprop(hos)	0.02/0.06	ND	0.02	Pass
Etofenprox	0.02/0.06	ND	0.02	Pass
Etoxazole	0.02/0.06	ND	1.5	Pass
Fenhexamid	0.017/0.05	ND	10.0	Pass
Fenoxycarb	0.02/0.06	ND	0.02	Pass
Fenpyroximate	0.02/0.06	ND	2.0	Pass
Fipronil	0.02/0.06	ND	0.02	Pass
Flonicamid	0.02/0.06	ND	2.0	Pass
Fludioxonil	0.02/0.06	ND	30.0	Pass
Hexythiazox	0.02/0.06	ND	2.0	Pass
Imazalil	0.02/0.06	ND	0.02	Pass
Imidacloprid	0.02/0.06	ND	3.0	Pass
Kresoxim Methyl	0.02/0.06	ND	1.0	Pass
Malathion	0.017/0.05	ND	5.0	Pass
Metalaxyl	0.017/0.05	ND	15.0	Pass
Methiocarb	0.02/0.06	ND	0.02	Pass
Methomyl	0.013/0.04	ND	0.1	Pass
Methyl parathion	0.02/0.06	ND	0.02	Pass
Mevinphos	0.02/0.06	ND	0.02	Pass
Myclobutanil	0.02/0.06	ND	9.0	Pass
Naled	0.017/0.05	ND	0.5	Pass
Oxamyl	0.013/0.04	ND	0.2	Pass
Paclobutrazol	0.02/0.06	ND	0.02	Pass
Pentachloronitrobenzene	0.017/0.05	ND	0.2	Pass
Permethrins	0.10/0.30	ND	20.0	Pass
Phosmet	0.02/0.06	ND	0.2	Pass
Piperonyl Butoxide	0.02/0.06	ND	8.0	Pass
Prallethrin	0.04/0.10	ND	0.4	Pass
Propiconazole	0.02/0.06	ND	20.0	Pass
Propoxur	0.013/0.04	ND	0.013	Pass
Pyrethrins	0.15/0.50	ND	1.0	Pass
Pyridaben	0.017/0.05	ND	3.0	Pass
Spinetoram	0.02/0.06	ND	3.0	Pass
Spinosad	0.02/0.06	ND	3.0	Pass
Spiromesifen	0.04/0.10	ND	12.0	Pass
Spirotetramat	0.02/0.06	ND	13.0	Pass
Spiroxamine	0.017/0.05	ND	0.017	Pass
Tebuconazole	0.02/0.06	ND	2.0	Pass
Thiacloprid	0.013/0.04	ND	0.013	Pass
Thiamethoxam	0.02/0.06	ND	4.5	Pass

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Trifloxystrobin	0.02/0.06	ND	30.0	Pass

Residual Solvent Screen ✓ Pass

08/19/2025

Method: MF-CHEM-32

Instrument: Gas Chromatography Mass Spectrometry (GC/MS)

Analyte	LOD/LOQ (ppm)	Findings (ppm)	Limit (ppm)	Status
1,2-Dichloroethane	0.5/0.5	ND	1	Pass
Acetone	57/200	ND	5000	Pass
Acetonitrile	56/200	ND	410	Pass
Benzene	0.5/0.5	ND	1	Pass
n-Butane	45/200	ND	5000	Pass
Chloroform	0.5/0.5	ND	1	Pass
Ethanol	37/200	ND	5000	Pass
Ethyl acetate	38/200	ND	5000	Pass
Ethyl ether	37/200	ND	5000	Pass
Ethylene oxide	0.1/0.5	ND	1	Pass
n-Heptane	135/200	ND	5000	Pass
n-Hexane	49/200	ND	290	Pass
Isopropyl alcohol	57/200	ND	5000	Pass
Methanol	37/200	ND	3000	Pass
Methylene chloride	0.1/0.5	ND	1	Pass
n-Pentane	37/200	ND	5000	Pass
Propane	72/200	ND	5000	Pass
Toluene	49/200	ND	890	Pass
Total xylenes (ortho-, meta-, para-)	58/200	ND	2170	Pass
Trichloroethylene	0.5/0.5	ND	1	Pass

Heavy Metal Screen ✓ Pass

08/19/2025

Method: MF-CHEM-16

Instrument: Inductively Coupled Plasma Mass Spectrometry (ICP-MS)

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Arsenic	0.003/0.05	ND	1.5	Pass
Cadmium	0.008/0.05	ND	0.5	Pass
Mercury	0.002/0.05	ND	3	Pass
Lead	0.01/0.125	ND	0.5	Pass

Foreign Material ✓ Pass

08/19/2025

Method: MF-CHEM-7

Analyte	Findings	Limit	Status
Sand, Soils, Cinders, and Dirt	ND	25%	Pass
Mold	ND	25%	Pass
Imbedded Foreign Material	ND	25%	Pass
Insect Fragment	ND	1 per 3g	Pass
Hair	ND	1 per 3g	Pass
Mammalian Excreta	ND	1 per 3g	Pass

Mycotoxin Screen ✓ Pass

08/20/2025

Method: MF-CHEM-13

Instrument: Liquid Chromatography Tandem Mass Spectrometry (LC-MS/MS) & Gas Chromatography Tandem Mass Spectrometry (GC-MS/MS)

Analyte	LOD/LOQ (µg/kg)	Findings (µg/kg)	Limit (µg/kg)	Status
Aflatoxin B1	2/5	ND	-	-
Aflatoxin B2	2/5	ND	-	-
Aflatoxin G1	2/5	ND	-	-
Aflatoxin G2	2/5	ND	-	-
Total Aflatoxins	8/20	ND	20	Pass
Ochratoxin A	6/18	ND	20	Pass

ND = None Detected
LOD = Limit of Detection
LOQ = Limit of Quantitation

Reported by



Vu Lam
Lab Co Director



Scan to verify

ANALYZED BY:

Anresco Laboratories
1375 Van Dyke Avenue,
San Francisco, CA 94124

CUSTOMER:

Surly Brewing Company
4811 Dusharme Dr
Brooklyn Center, MN 55429



SAMPLE INFORMATION

Sample No.: 1330010
Product Name: Find Wunder: Higher Vibes Grapefruit Hibiscus
Matrix: Edible (Carbonated Beverage)
Lot #: WSTGH111

Date Collected: 08/13/2025
Date Received: 08/13/2025
Date Reported: 08/15/2025

TEST SUMMARY

Cannabinoid Profile: ✔ Pass
Pesticide Residue Screen: ✔ Pass
Heavy Metal Screen: ✔ Pass
Mycotoxin Screen: ✔ Pass

Microbiological Screen: ✔ Pass
Residual Solvent Screen: ✔ Pass
Foreign Material: ✔ Pass

Cannabinoid Profile ✔ Pass

08/15/2025

Method: MF-CHEM-15
Instrument: Liquid Chromatography Diode Array Detector (LC-DAD)
Limit of Detection 0.0008 mg/g
Limit of Quantitation 0.0025 mg/g

Cannabinoid	mg/g	%	mg/ml	mg/serving	mg/package	Labeled mg/serving	% Difference	Status
Δ8-THC	ND	ND	ND	ND	ND	-	-	-
Δ9-THC	0.0298	0.00298	0.0305	5.39	10.79	5	7.86	Pass
Δ9-THCA	ND	ND	ND	ND	ND	-	-	-
THCV	ND	ND	ND	ND	ND	-	-	-
THCVA	ND	ND	ND	ND	ND	-	-	-
CBD	ND	ND	ND	ND	ND	-	-	-
CBDA	ND	ND	ND	ND	ND	-	-	-
CBC	ND	ND	ND	ND	ND	-	-	-
CBCA	ND	ND	ND	ND	ND	-	-	-
CBDV	ND	ND	ND	ND	ND	-	-	-
CBG	0.0313	0.00313	0.0320	5.66	11.33	5	13.28	-
CBGA	ND	ND	ND	ND	ND	-	-	-
CBN	ND	ND	ND	ND	ND	-	-	-
Total THC	0.0298	0.00298	0.0305	5.39	10.79	-	-	-
Total CBD	ND	ND	ND	ND	ND	-	-	-
Total Cannabinoids	0.0611	0.00611	0.0625	11.06	22.11	-	-	-
Sum of Cannabinoids	0.0611	0.00611	0.0625	11.06	22.11	-	-	-
Serving Weight (g)	180.9648							
Package Weight (g)	361.9296							
g/ml Conversion Factor	1.0224							

Total THC = Δ8-THC + Δ9-THC + (0.877 * THCA)
Total CBD = CBD + (0.877 * CBDA)
Total Cannabinoids = Σ (neutral cannabinoids) + [0.877 * Σ (acidic cannabinoids)]

Comments This result of this sample is confirmed with a retest.

Microbiological Screen ✔ Pass

08/15/2025

Analyte	Method	Findings	Units	Status
Salmonella	MF-MICRO-11	Not Detected/25g	/1g	Pass
STEC	MF-MICRO-18	Not Detected/25g	/1g	Pass

Pesticide Residue Screen ✔ Pass

08/15/2025

Method: MF-CHEM-13

Instrument: Liquid Chromatography Tandem Mass Spectrometry (LC-MS/MS) & Gas Chromatography Tandem Mass Spectrometry (GC-MS/MS)

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Abamectin	0.04/0.10	ND	0.3	Pass
Acephate	0.02/0.06	ND	5.0	Pass
Acequinocyl	0.04/0.10	ND	4.0	Pass
Acetamiprid	0.017/0.05	ND	5.0	Pass
Aldicarb	0.02/0.06	ND	0.02	Pass
Azoxystrobin	0.02/0.06	ND	40.0	Pass
Bifenazate	0.02/0.06	ND	5.0	Pass
Bifenthrin	0.04/0.10	ND	0.5	Pass
Boscalid	0.02/0.06	ND	10.0	Pass
Captan	0.2/0.6	ND	5.0	Pass
Carbaryl	0.02/0.06	ND	0.5	Pass
Carbofuran	0.017/0.05	ND	0.017	Pass
Chlorantraniliprole	0.02/0.06	ND	40.0	Pass
Chlordane	0.02/0.06	ND	0.02	Pass
Chlorfenapyr	0.02/0.06	ND	0.02	Pass
Chlorpyrifos	0.02/0.06	ND	0.02	Pass
Clofentezine	0.02/0.06	ND	0.5	Pass
Coumaphos	0.02/0.06	ND	0.02	Pass
Cyfluthrin	0.10/0.30	ND	1.0	Pass
Cypermethrin	0.10/0.30	ND	1.0	Pass
Daminozide	0.017/0.05	ND	0.017	Pass
DDVP (Dichlorvos)	0.013/0.04	ND	0.013	Pass
Diazinon	0.017/0.05	ND	0.2	Pass
Dimethoate	0.017/0.05	ND	0.017	Pass
Dimethomorph	0.017/0.05	ND	20.0	Pass
Ethoprop(hos)	0.02/0.06	ND	0.02	Pass
Etofenprox	0.02/0.06	ND	0.02	Pass
Etoxazole	0.02/0.06	ND	1.5	Pass
Fenhexamid	0.017/0.05	ND	10.0	Pass
Fenoxycarb	0.02/0.06	ND	0.02	Pass
Fenpyroximate	0.02/0.06	ND	2.0	Pass
Fipronil	0.02/0.06	ND	0.02	Pass
Flonicamid	0.02/0.06	ND	2.0	Pass
Fludioxonil	0.02/0.06	ND	30.0	Pass
Hexythiazox	0.02/0.06	ND	2.0	Pass
Imazalil	0.02/0.06	ND	0.02	Pass
Imidacloprid	0.02/0.06	ND	3.0	Pass
Kresoxim Methyl	0.02/0.06	ND	1.0	Pass
Malathion	0.017/0.05	ND	5.0	Pass
Metalaxyl	0.017/0.05	ND	15.0	Pass
Methiocarb	0.02/0.06	ND	0.02	Pass
Methomyl	0.013/0.04	ND	0.1	Pass
Methyl parathion	0.02/0.06	ND	0.02	Pass
Mevinphos	0.02/0.06	ND	0.02	Pass
Myclobutanil	0.02/0.06	ND	9.0	Pass
Naled	0.017/0.05	ND	0.5	Pass
Oxamyl	0.013/0.04	ND	0.2	Pass
Paclobutrazol	0.02/0.06	ND	0.02	Pass
Pentachloronitrobenzene	0.017/0.05	ND	0.2	Pass
Permethrins	0.10/0.30	ND	20.0	Pass
Phosmet	0.02/0.06	ND	0.2	Pass
Piperonyl Butoxide	0.02/0.06	ND	8.0	Pass
Prallethrin	0.04/0.10	ND	0.4	Pass
Propiconazole	0.02/0.06	ND	20.0	Pass
Propoxur	0.013/0.04	ND	0.013	Pass
Pyrethrins	0.15/0.50	ND	1.0	Pass
Pyridaben	0.017/0.05	ND	3.0	Pass
Spinetoram	0.02/0.06	ND	3.0	Pass
Spinosad	0.02/0.06	ND	3.0	Pass
Spiromesifen	0.04/0.10	ND	12.0	Pass
Spirotetramat	0.02/0.06	ND	13.0	Pass
Spiroxamine	0.017/0.05	ND	0.017	Pass
Tebuconazole	0.02/0.06	ND	2.0	Pass
Thiacloprid	0.013/0.04	ND	0.013	Pass
Thiamethoxam	0.02/0.06	ND	4.5	Pass

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Trifloxystrobin	0.02/0.06	ND	30.0	Pass

Residual Solvent Screen ✓ Pass

08/15/2025

Method: MF-CHEM-32

Instrument: Gas Chromatography Mass Spectrometry (GC/MS)

Analyte	LOD/LOQ (ppm)	Findings (ppm)	Limit (ppm)	Status
1,2-Dichloroethane	0.5/0.5	ND	1	Pass
Acetone	57/200	ND	5000	Pass
Acetonitrile	56/200	ND	410	Pass
Benzene	0.5/0.5	ND	1	Pass
n-Butane	45/200	ND	5000	Pass
Chloroform	0.5/0.5	ND	1	Pass
Ethanol	37/200	1180.00	5000	Pass
Ethyl acetate	38/200	ND	5000	Pass
Ethyl ether	37/200	ND	5000	Pass
Ethylene oxide	0.1/0.5	ND	1	Pass
n-Heptane	135/200	ND	5000	Pass
n-Hexane	49/200	ND	290	Pass
Isopropyl alcohol	57/200	ND	5000	Pass
Methanol	37/200	ND	3000	Pass
Methylene chloride	0.1/0.5	ND	1	Pass
n-Pentane	37/200	ND	5000	Pass
Propane	72/200	ND	5000	Pass
Toluene	49/200	ND	890	Pass
Total xylenes (ortho-, meta-, para-)	58/200	ND	2170	Pass
Trichloroethylene	0.5/0.5	ND	1	Pass

Heavy Metal Screen ✓ Pass

08/15/2025

Method: MF-CHEM-16

Instrument: Inductively Coupled Plasma Mass Spectrometry (ICP-MS)

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Arsenic	0.003/0.05	<LOQ	1.5	Pass
Cadmium	0.008/0.05	ND	0.5	Pass
Mercury	0.002/0.05	ND	3	Pass
Lead	0.01/0.125	ND	0.5	Pass

Foreign Material ✓ Pass

08/15/2025

Method: MF-CHEM-7

Analyte	Findings	Limit	Status
Sand, Soils, Cinders, and Dirt	ND	25%	Pass
Mold	ND	25%	Pass
Imbedded Foreign Material	ND	25%	Pass
Insect Fragment	ND	1 per 3g	Pass
Hair	ND	1 per 3g	Pass
Mammalian Excreta	ND	1 per 3g	Pass

Mycotoxin Screen ✓ Pass

08/15/2025

Method: MF-CHEM-13

Instrument: Liquid Chromatography Tandem Mass Spectrometry (LC-MS/MS) & Gas Chromatography Tandem Mass Spectrometry (GC-MS/MS)

Analyte	LOD/LOQ (µg/kg)	Findings (µg/kg)	Limit (µg/kg)	Status
Aflatoxin B1	2/5	ND	-	-
Aflatoxin B2	2/5	ND	-	-
Aflatoxin G1	2/5	ND	-	-
Aflatoxin G2	2/5	ND	-	-
Total Aflatoxins	8/20	ND	20	Pass
Ochratoxin A	6/18	ND	20	Pass

ND = None Detected
LOD = Limit of Detection
LOQ = Limit of Quantitation

Reported by



Vu Lam
Lab Co Director



Scan to verify

ANALYZED BY:

Anresco Laboratories
1375 Van Dyke Avenue,
San Francisco, CA 94124

CUSTOMER:

Surly Brewing Company
4811 Dusharme Dr
Brooklyn Center, MN 55429



SAMPLE INFORMATION

Sample No.: 1330011
Product Name: Find Wunder: Higher Vibes Watermelon Basil
Matrix: Edible (Carbonated Beverage)
Lot #: WSTWB111

Date Collected: 08/13/2025
Date Received: 08/13/2025
Date Reported: 08/15/2025

TEST SUMMARY

Cannabinoid Profile: ✔ Pass
Residual Solvent Screen: ✔ Pass
Foreign Material: ✔ Pass

Pesticide Residue Screen: ✔ Pass
Heavy Metal Screen: ✔ Pass
Mycotoxin Screen: ✔ Pass

Cannabinoid Profile ✔ Pass

08/15/2025

Method: MF-CHEM-15
Instrument: Liquid Chromatography Diode Array Detector (LC-DAD)
Limit of Detection 0.0008 mg/g
Limit of Quantitation 0.0025 mg/g

Cannabinoid	mg/g	%	mg/ml	mg/serving	mg/package	Labeled mg/serving	% Difference	Status
Δ8-THC	ND	ND	ND	ND	ND	-	-	-
Δ9-THC	0.0295	0.00295	0.0302	5.34	10.68	5	6.79	Pass
Δ9-THCA	ND	ND	ND	ND	ND	-	-	-
THCV	ND	ND	ND	ND	ND	-	-	-
THCVA	ND	ND	ND	ND	ND	-	-	-
CBD	ND	ND	ND	ND	ND	-	-	-
CBDA	ND	ND	ND	ND	ND	-	-	-
CBC	ND	ND	ND	ND	ND	-	-	-
CBCA	ND	ND	ND	ND	ND	-	-	-
CBDV	ND	ND	ND	ND	ND	-	-	-
CBG	0.0284	0.00284	0.0290	5.14	10.28	5	2.81	-
CBGA	ND	ND	ND	ND	ND	-	-	-
CBN	ND	ND	ND	ND	ND	-	-	-
Total THC	0.0295	0.00295	0.0302	5.34	10.68	-	-	-
Total CBD	ND	ND	ND	ND	ND	-	-	-
Total Cannabinoids	0.0579	0.00579	0.0592	10.48	20.96	-	-	-
Sum of Cannabinoids	0.0579	0.00579	0.0592	10.48	20.96	-	-	-
Serving Weight (g)	181.0002							
Package Weight (g)	362.0004							
g/ml Conversion Factor	1.0226							

Total THC = Δ8-THC + Δ9-THC + (0.877 * THCA)
Total CBD = CBD + (0.877 * CBDA)
Total Cannabinoids = Σ (neutral cannabinoids) + [0.877 * Σ (acidic cannabinoids)]

Pesticide Residue Screen ✔ Pass

08/15/2025

Method: MF-CHEM-13
Instrument: Liquid Chromatography Tandem Mass Spectrometry (LC-MS/MS) & Gas Chromatography Tandem Mass Spectrometry (GC-MS/MS)

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Abamectin	0.04/0.10	ND	0.3	Pass
Acephate	0.02/0.06	ND	5.0	Pass
Acequinocyl	0.04/0.10	ND	4.0	Pass
Acetamiprid	0.017/0.05	ND	5.0	Pass

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Aldicarb	0.02/0.06	ND	0.02	Pass
Azoxystrobin	0.02/0.06	ND	40.0	Pass
Bifenazate	0.02/0.06	ND	5.0	Pass
Bifenthrin	0.04/0.10	ND	0.5	Pass
Boscalid	0.02/0.06	ND	10.0	Pass
Captan	0.2/0.6	ND	5.0	Pass
Carbaryl	0.02/0.06	ND	0.5	Pass
Carbofuran	0.017/0.05	ND	0.017	Pass
Chlorantraniliprole	0.02/0.06	ND	40.0	Pass
Chlordane	0.02/0.06	ND	0.02	Pass
Chlorfenapyr	0.02/0.06	ND	0.02	Pass
Chlorpyrifos	0.02/0.06	ND	0.02	Pass
Clofentezine	0.02/0.06	ND	0.5	Pass
Coumaphos	0.02/0.06	ND	0.02	Pass
Cyfluthrin	0.10/0.30	ND	1.0	Pass
Cypermethrin	0.10/0.30	ND	1.0	Pass
Daminozide	0.017/0.05	ND	0.017	Pass
DDVP (Dichlorvos)	0.013/0.04	ND	0.013	Pass
Diazinon	0.017/0.05	ND	0.2	Pass
Dimethoate	0.017/0.05	ND	0.017	Pass
Dimethomorph	0.017/0.05	ND	20.0	Pass
Ethoprop(hos)	0.02/0.06	ND	0.02	Pass
Etofenprox	0.02/0.06	ND	0.02	Pass
Etoxazole	0.02/0.06	ND	1.5	Pass
Fenhexamid	0.017/0.05	ND	10.0	Pass
Fenoxycarb	0.02/0.06	ND	0.02	Pass
Fenpyroximate	0.02/0.06	ND	2.0	Pass
Fipronil	0.02/0.06	ND	0.02	Pass
Flonicamid	0.02/0.06	ND	2.0	Pass
Fludioxonil	0.02/0.06	ND	30.0	Pass
Hexythiazox	0.02/0.06	ND	2.0	Pass
Imazalil	0.02/0.06	ND	0.02	Pass
Imidacloprid	0.02/0.06	ND	3.0	Pass
Kresoxim Methyl	0.02/0.06	ND	1.0	Pass
Malathion	0.017/0.05	ND	5.0	Pass
Metalaxyl	0.017/0.05	ND	15.0	Pass
Methiocarb	0.02/0.06	ND	0.02	Pass
Methomyl	0.013/0.04	ND	0.1	Pass
Methyl parathion	0.02/0.06	ND	0.02	Pass
Mevinphos	0.02/0.06	ND	0.02	Pass
Myclobutanil	0.02/0.06	ND	9.0	Pass
Naled	0.017/0.05	ND	0.5	Pass
Oxamyl	0.013/0.04	ND	0.2	Pass
Paclobutrazol	0.02/0.06	ND	0.02	Pass
Pentachloronitrobenzene	0.017/0.05	ND	0.2	Pass
Permethrins	0.10/0.30	ND	20.0	Pass
Phosmet	0.02/0.06	ND	0.2	Pass
Piperonyl Butoxide	0.02/0.06	ND	8.0	Pass
Prallethrin	0.04/0.10	ND	0.4	Pass
Propiconazole	0.02/0.06	ND	20.0	Pass
Propoxur	0.013/0.04	ND	0.013	Pass
Pyrethrins	0.15/0.50	ND	1.0	Pass
Pyridaben	0.017/0.05	ND	3.0	Pass
Spinetoram	0.02/0.06	ND	3.0	Pass
Spinosad	0.02/0.06	ND	3.0	Pass
Spiromesifen	0.04/0.10	ND	12.0	Pass
Spirotetramat	0.02/0.06	ND	13.0	Pass
Spiroxamine	0.017/0.05	ND	0.017	Pass
Tebuconazole	0.02/0.06	ND	2.0	Pass
Thiacloprid	0.013/0.04	ND	0.013	Pass
Thiamethoxam	0.02/0.06	ND	4.5	Pass
Trifloxystrobin	0.02/0.06	ND	30.0	Pass

Residual Solvent Screen ✔ Pass

08/15/2025

Method: MF-CHEM-32

Instrument: Gas Chromatography Mass Spectrometry (GC/MS)

Analyte	LOD/LOQ (ppm)	Findings (ppm)	Limit (ppm)	Status
1,2-Dichloroethane	0.5/0.5	ND	1	Pass
Acetone	57/200	ND	5000	Pass
Acetonitrile	56/200	ND	410	Pass
Benzene	0.5/0.5	ND	1	Pass
n-Butane	45/200	ND	5000	Pass
Chloroform	0.5/0.5	ND	1	Pass
Ethanol	37/200	ND	5000	Pass
Ethyl acetate	38/200	ND	5000	Pass
Ethyl ether	37/200	ND	5000	Pass
Ethylene oxide	0.1/0.5	ND	1	Pass
n-Heptane	135/200	ND	5000	Pass
n-Hexane	49/200	ND	290	Pass
Isopropyl alcohol	57/200	ND	5000	Pass
Methanol	37/200	ND	3000	Pass
Methylene chloride	0.1/0.5	ND	1	Pass
n-Pentane	37/200	ND	5000	Pass
Propane	72/200	ND	5000	Pass
Toluene	49/200	ND	890	Pass
Total xylenes (ortho-, meta-, para-)	58/200	ND	2170	Pass
Trichloroethylene	0.5/0.5	ND	1	Pass

Heavy Metal Screen ✔ Pass

08/15/2025

Method: MF-CHEM-16

Instrument: Inductively Coupled Plasma Mass Spectrometry (ICP-MS)

Analyte	LOD/LOQ (µg/g)	Findings (µg/g)	Limit (µg/g)	Status
Arsenic	0.003/0.05	<LOQ	1.5	Pass
Cadmium	0.008/0.05	ND	0.5	Pass
Mercury	0.002/0.05	ND	3	Pass
Lead	0.01/0.125	ND	0.5	Pass

Foreign Material ✔ Pass

08/15/2025

Method: MF-CHEM-7

Analyte	Findings	Limit	Status
Sand, Soils, Cinders, and Dirt	ND	25%	Pass
Mold	ND	25%	Pass
Imbedded Foreign Material	ND	25%	Pass
Insect Fragment	ND	1 per 3g	Pass
Hair	ND	1 per 3g	Pass
Mammalian Excreta	ND	1 per 3g	Pass

Mycotoxin Screen ✔ Pass

08/15/2025

Method: MF-CHEM-13

Instrument: Liquid Chromatography Tandem Mass Spectrometry (LC-MS/MS) & Gas Chromatography Tandem Mass Spectrometry (GC-MS/MS)

Analyte	LOD/LOQ (µg/kg)	Findings (µg/kg)	Limit (µg/kg)	Status
Aflatoxin B1	2/5	ND	-	-
Aflatoxin B2	2/5	ND	-	-
Aflatoxin G1	2/5	ND	-	-
Aflatoxin G2	2/5	ND	-	-
Total Aflatoxins	8/20	ND	20	Pass
Ochratoxin A	6/18	ND	20	Pass

ND = None Detected
LOD = Limit of Detection
LOQ = Limit of Quantitation

Reported by



Vu Lam
Lab Co Director



Scan to verify